THE GARDEN FURNITURE CENTRE LTD

EST. 1999

Teak Aftercare Instructions

It's no secret that Teak is the best wood for use in outdoor furniture due to its high oil content, this offers a natural protection from the elements and insect damage. Crafted from Grade A teak, our furniture is built to last a lifetime.

Our Grade A Teak is not susceptible to cracking, warping or splitting. And if left to age gracefully it will take on a lovely silver-grey patina. The beauty of Teak means you don't have to do anything at all.

Naturally low-maintenance, our teak furniture needs very little aftercare. To preserve its beauty and performance over time, we recommend using high-quality water-based products, such as the Golden Care range.

For a list of our Teak care products check out our Golden Care range on our website using the QR code below.

Our Step by Step Guide to restoring your Teak Furniture

Step one:

We recommend waiting for a clear, dry day to start cleaning your Teak. The wood can be pressure-washed on low setting or cleaned with soapy water and elbow grease.

Step Two:

Next is to sand down the wood, always moving with the grain. We recommend using an 80-120 grit to remove any rough spots and increasing to 180-220 for a nice smooth finish.

Step Three:

Finally, apply your chosen Golden Care Teak Protector in a thin layer using a brush. Once dry, your furniture is refreshed, protected, and ready to shine as your garden's centrepiece.

GARDEN FURNITURE CENTRE
EST. 1999